



Flush Pump

PART NO: PLI-FP-SS-TT

The PLI Flush Pump with stainless steel tank and trolley holds 28 litres of Liquid Valve Flush, used for injecting Liquid Valve Flush into the valve for cleaning internal lube ports & components prior to lubing.

PART NUMBER

PLI-FP-SS-TT

SPARE PARTS

- | | |
|----|--------------------------------------|
| 1 | All Stainless Steel Trolley and Tank |
| 2 | Filter Regulator |
| 3 | Control Valve for Air Motor On/Off |
| 4 | Flush Discharge Hose Connection |
| 5 | Pressure Release Valve to Tank |
| 6 | 10,000 PSI Liquid Pump |
| 7 | Pneumatic Tyres |
| 8 | Air Motor Filter |
| 9 | Filler |
| 10 | 28 Litre Tank |

